



#	CONNECTION DIAGRAM ELEMENTS DESCRIPTION
1	OEM car monitor (head unit/HU), front view
2	OEM car monitor (head unit/HU), rear view
3	Front view camera (not included in the package)
4	Rear view camera (not included in the package), OEM or additionally installed with the controller
5	Rear and front view camera controller – RFCC
6	Front view camera connection input – F-CAM
7	Rear view camera connection input – R-CAM
8	Front view camera power output – 12V OUT
9	Rear view camera power output – 6V OUT
10, 11	Adapter connectors for Plug&Play connection to OEM wiring
12, 13	Adapter sockets for Plug&Play connection to OEM wiring